




**BROOK SLIPCOVERED PLATFORM BED TWIN - ASSEMBLY INSTRUCTIONS**


**PARTS INCLUDED**

- A. HEADBOARD (1)
- B. SIDE RAILS (2)
- C. FOOTBOARD (1)
- D. SLAT ROLL (1)
- E. CENTER SUPPORT SLAT (1)
- F. CENTER SUPPORT SLAT FOOT (WITH ADJUSTABLE GLIDE) (1)

NO.		DESCRIPTION	Qty
1		Screws (3cm)	20 pcs.
2		Screws (5cm)	2 pcs.
3		Allen key (0.5cm Dia.)	1 pc.

**TOOLS NEEDED**

Phillips-head Screwdriver (not included)



**ASSEMBLY INSTRUCTIONS**

- Bed must be assembled by at least two people.
  - Please read instructions carefully before assembling bed.
  - Use the above parts and hardware list to identify each component.
  - Keep all packing materials until assembly is complete to avoid loss of smaller parts.
1. Stand the Headboard (A) upright and attach Side Rails (B), as shown in Diagram I.
  2. Repeat above procedure to attach the Footboard (C) and Side Rail (B).
  3. Attach the Center Support Foot (F) to the Center Support Slat (E), as shown in Diagram II.
  4. Attach the Center Support Slat (E) to the U-shaped wood blocks on Headboard (A) and Footboard (C), and tighten with Long Screw (2), as shown in Diagram III.
  5. Place the Slats (D) on the top of the Side Rail's side slats and fasten using Screw (1), as shown in Diagram IV.

**CARE INSTRUCTIONS**

Spot clean only with a soft, damp cloth.

