









RHTEEN

SABINE UPHOLSTERED PLATFORM TWIN BED

PARTS INCLUDED

- A [1] Headboard
- B [2] Side Rail
- C [1] Footboard
- D [4] Slat
- E [2] Platform Panel

NO	HARDWARE & PARTS ENCLOSED		QTY
1		Screw (4cm)	24 pcs
2		Allen Key	1 pcs
3		Allen Head Bolt(0.6cm Dia)	8 pcs
4		Thread Rod	4 pcs
5		Curved Washer	4 pcs
6		Lock Washer	4 pcs
7		Nut	4 pcs
8		Spanner Wrench	1 pcs

TOOLS NEEDED

Phillips Screwdriver (not included)



ASSEMBLY INSTRUCTIONS

- Bed must be assembled by at least two people.
 - Please read instructions carefully before assembling bed.
 - Use the above parts and hardware list to identify each component.
 - Keep all packing materials until assembly is complete to avoid loss of smaller parts.
1. Stand the Headboard (A) upright and attach Side Rails (B), repeat the same procedure to attach the Footboard (C), then tighten with Allen Head Bolt (3) & Allen Key (2), as shown in Diagram I.
 2. Lock the Headboard (A) & Footboard (C) with Thread Rod (4), Curved Washers (5), Lock Washers (6) and Nuts (7), then tighten with Spanner Wrench (8), as shown in Diagram II.
 3. Place the Slat (D) into the cleats on the inside of the Side Rails (B).
Screw the ends of the slats to the cleats using Screw (1), then lay the platform panel (E) on the top, as shown in Diagram III.

CARE INSTRUCTIONS

1. Spot clean only with a soft, damp cloth.
2. Do not use abrasive cleanser.

