













RH BABY & CHILD

RH TEEN

SLOANE TRUNDLE BED QUEEN - ASSEMBLY INSTRUCTIONS

PARTS INCLUDED

- A. HEADBOARD (1)
- B. SIDE RAIL (2)
- C. FOOTBOARD (1)
- D. SLATS (4)
- E. PLATFORMS (2)
- F. TRUNDLE (1)
- G. CENTER SUPPORT SLAT (1)

NO.	HARDWARE & PARTS ENCLOSED	QTY
1	 Thread Rod (0.8cm Diam*11.5cm)	10 Pcs
2	 Curved Washer	10 Pcs
3	 Lock Washer	10 Pcs
4	 Nut	10 Pcs
5	 Spanner Wrench	1 Pc
6	 Screw (3cm)	16 Pcs
7	 Screw (4cm)	8 Pcs
8	 Allen Head Bolt (0.8cm Diam*3cm)	2 Pcs
9	 Allen Head Bolt (0.6cm Diam*3cm)	2 Pcs
10	 Lock Washer (1.9cm Diam)	2 Pcs
11	 Allen Wrench (0.5cm Diam)	1 Pc
12	 L-Shaped Bracket	2 Pcs

TOOLS NEEDED

Phillips Screwdriver (not included)



ASSEMBLY INSTRUCTIONS

- Bed must be assembled by at least two people.
 - Please read instructions carefully before assembling bed.
 - Use the parts and hardware lists above to identify each component.
 - Keep all packing materials until assembly is complete to avoid loss of smaller parts.
1. Stand the Headboard (A) upright and attach the Side Rail (B) by using Thread Rod (1), Curved Washer (2), Lock Washer (3), Nut (4) and Spanner Wrench (5), as shown in Diagram I. Do not tighten.
 2. Repeat the above procedure to attach the Footboard (C) to Side Rail (B), then tighten all the bolts.
 3. Install the L-Shaped Bracket (12) to Headboard (A) and Footboard (C) by using Allen Head Bolt (8) and Allen Wrench (11). Place the Center Support Slat (G) to the L-Shaped Bracket (12) and lock both ends of the slat to the bracket by using Allen Head Bolt (9), Lock Washer (10) and Allen Wrench (11), as shown in Diagram II.
 4. Place the Slats (D) on the top of the Side Rail's side slats and fasten using Screws (6), as shown in Diagram II.
 5. Lay the Platform Panel (E) on the top of the Slats (D), then screw the Screws (7), as shown in Diagram IV.
 6. Push the Trundle (F) into the bed frame, making sure the Trundle (F) front panel is flush with Side Rail (B), as shown in Diagram V.

CARE INSTRUCTIONS

Spot clean only with a soft, damp cloth.

