






SLOANE STORAGE BED FULL & QUEEN - ASSEMBLY INSTRUCTIONS

PARTS INCLUDED

- A. HEADBOARD (1)
- B. DRAWER FRAME (1)
- C. SIDE RAILS (2)
- D. SUPPORT SLAT (1)
- E. CENTER SUPPORT SLAT FOOT (WITH ADJUSTABLE GLIDE) (1)
- F. PLATFORM PANELS (2)

NO.	ITEM	DESCRIPTION	QTY
1		Allen Key (0.5cm Dia.)	1 pc.
2		Screws (5cm)	2 pcs.
3		Allen-Head Bolt (0.8cm Dia.*3.5cm)	6 pcs.
4		Allen-Head Bolt (0.8cm Dia.*5.5cm)	2 pcs.

TOOLS NEEDED

Phillips-Head Screwdriver (not included) 

ASSEMBLY INSTRUCTIONS

Bed must be assembled by at least two people.

Please read instructions carefully before assembling bed.

Use the above parts and hardware list to identify each component.

Keep all packing materials until assembly is complete to avoid loss of smaller parts.

1. Stand the Headboard (A) upright and hook Side Panels (C) into Headboard (A), as shown in Diagram I.
2. Stand the Side Rails (C) upright and hook the Drawer Framing (B) into Side Panels, as shown in Diagram II.
3. Fasten Drawer Framing (B) to Side Rails with Allen Head Bolt (4) using Allen Key (1), as shown in Diagram III.
4. Attach the Center Support Slat Foot (E) to the Support Slat (D), as shown in Diagram IV.
5. Place the Support Slat (D) to the U-shaped brackets on the Headboard (A) and fasten with Screws (2), as shown in Diagram V.
6. Lay the Platform Panels (F) flat on the top of the Drawer Framing (B) and slats of Side Rails (C), as shown in Diagram VI.

CARE INSTRUCTIONS

Spot clean only with a soft, damp cloth.

