

### SLOANE TRUNDLE DAYBED FULL & QUEEN - ASSEMBLY INSTRUCTIONS

#### **PARTS INCLUDED**

A.SIDE RAILS (2)
B.FRONT RAIL (1)
C.HEADBOARD (1)
D.SLATS (4)
E.PLATFORM PANELS (2)

NO.	DESCRIPTION		QTY
1	Γ	Allen key (0.5cm Dia.)	1 pc.
2		Screws (3cm)	16 pcs.
3		Screws (4cm)	8 pcs.

### **TOOLS NEEDED**

F.TRUNDLE (1)

Phillips-head Screwdriver (not included)



# **ASSEMBLY INSTRUCTIONS**

- Bed must be assembled by at least two people.
- Please read instructions carefully before assembling bed.
- Use the above parts and hardware list to identify each component.
- Keep all packing materials until assembly is complete to avoid loss of smaller parts.
- 1. Stand the Headboard (C) upright and attach Side Rails (A), as shown in Diagram I.
- 2. Hook the Front rail (B) to the Side Rails (A), then tighten the bolts by using Allen Key (1), as shown in Diagram II.
- 3. Place the Slats (D) on the top of the Side Rail's side slats and fasten using Screw (3), as shown in Diagram III.
- 4. Lay the Platform Panels (E) on the top of the Slats (D), then fasten using Screw (2), as shown in Diagram IV.
- 5. Push the Trundle (F) into the daybed frame, making sure the Trundle front panel is flush with the daybed Front Panel (B).

## **CARE INSTRUCTIONS**

Spot clean only with a soft, damp cloth.

