

# RH TEEN

## TAREN LARGE PENDANT

### PARTS ENCLOSED:

- (A) Mounting Plate (1)
- (B) Plastic Wire Connector (2)
- (C) Ground Screw (1)
- (D) Mounting Screw (2)
- (E) Canopy (1)
- (F) Ring (1)
- (G) Pendant
- (H) Socket (3)
- (I) Bulb (3) (not included)

### IMPORTANT SAFETY INSTRUCTIONS:

THIS FIXTURE MUST BE INSTALLED BY A LICENSED ELECTRICIAN.  
This fixture has been rated for up to three (3) 40-watt maximum type B bulbs. To avoid the risk of fire, do not exceed the recommended wattage.

### WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb. Do not touch bulb when lamp is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

### THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE

### ASSEMBLY & INSTALLATION:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the pendant will be installed.
3. Connect the live wire (labeled with an "L") to the hot junction box wire with a plastic wire connector (B) and wrap the connection with electrical tape. Connect the neutral wire (labeled with an "N") to the neutral junction box wire with a plastic wire connector (B) and wrap the connection with electrical tape.
4. Attach the ground wire (not labeled) from the fixture to the ground junction box wire in the outlet box, or wrap the ground wire around the ground screw (C).
5. Attach the mounting plate (A) to the outlet box using the junction box mounting screws (D) and tighten.
6. Attach the canopy (E) to the mounting plate (A) using the ring (F) and tighten.
7. Insert (3) 40-watt max. bulbs (I) (not included) into the socket (H).
8. Restore power to the junction box and test fixture.
9. Installation is complete.

### CARE INSTRUCTIONS:

Do not use polishes or cleaners on your fixture.  
Just wipe clean with a soft cloth.

