


ZADIE TUFTED TWIN BED - ASSEMBLY INSTRUCTIONS












PARTS INCLUDED

- A [1] Headboard
- B [2] Side rail
- C [1] Footboard
- D [1] Slat Roll
- E [1] Center Support Slat
- F [1] Center Support Slat Foot

TOOLS NEEDED:

Phillips-head Screwdriver (not included)



NO	HARDWARE & PARTS ENCLOSED		QTY
1		Thread Rod	8 pcs
2		Curved Washer	8 pcs
3		Lock Washer	8 pcs
4		Nut	8 pcs
5		Spanner Wrench	1 pc
6		Screw (3cm)	22 Pcs
7		Allen Key	1 pc
8		Allen Head Bolt (0.6cm Dia)	2 Pcs
9		Allen Head Bolt (0.8cm Dia)	2 Pcs
10		L-Shaped Bracket	2 Pcs
11		Washer	2 Pcs

ASSEMBLY INSTRUCTIONS

- Bed must be assembled by at least two people.
 - Please read instructions carefully before assembling bed.
 - Use the above parts and hardware list to identify each component.
 - Keep all packing materials until assembly is complete to avoid loss of smaller parts.
1. Stand the headboard (A) upright and align the Side Rails (B) at the base of the headboard.
 2. Insert the Thread Rods (1) into the holes on the Side Rail (B), and attach Curved Washers (2), Lock Washers (3), Nuts (4) onto the Thread Rods (1). Tighten the Nuts (4) & Thread Rods (1) with Spanner Wrench (5) as shown in the Diagram I.
 3. Repeat above procedure to attached the Footboard (C)
 4. Tighten the Cross Support Slat Foot (F) to the Center Support Slat (E) with Screw (6), as shown in the Diagram II.
 5. Attach the L-Shaped Brackets (10) to the ends of Center Support Slat (E) by using Allen Head (8) and Washer (11), then tighten it by using Allen Key (7). Attach the L-Shaped Brackets (10) to the Headboard (A) and Footboard (C), then tighten Allen Head Bolt (9) with Allen Key (7), as shown in Diagram III.
 6. Place the Slat Roll (D) on the cleats on the inside of the Side Rail (B). Screw the ends of the Slats to the cleats using Screw (6), as shown in Diagram IV.

CARE INSTRUCTIONS

1. Spot clean only with a soft, damp cloth.

